

Lock-On Gutter Guard Installation

1. Starting at one end, slightly lift the shingles and slide the back edge of the gutter guard under the shingles. Next, push the front edge against the lip of the gutter until it locks in place. HINT: For leverage, run a screw driver through the mesh closest to the Lock-On edge and push/pull the gutter guard to the gutter. Repeat the process with the next gutter guard, avoiding gaps and overlaps.
2. When you get to the end of the gutter, you may have to shorten one length of the gutter guard. If so, simply cut off the excess.
3. For outside corners, cut a 45 degree angle off the opposite ends of two adjoining pieces. Slide the guard under the shingles and lock onto the gutter to form an accurate corner joint.
4. For inside corners, you must allow for the splash guard. Make a 3/4" cut out of the gutter guard to clear the splash guard. Next, cut a 45 degree angle off the opposite ends of two adjoining pieces. Slide the guard under the shingles and lock onto the gutter to form an accurate corner joint.