

## **Flex-A-Spout Installation**

Fully extend the Flex-A-Spout to its maximum length, then bend it into the desired water flow direction. (To prevent possible damage to downspout, expand Flex-A-Spout before attaching to downspout.)

The end that is not being attached to the downspout can be cut off.

Slide the end over the downspout elbow. Using 2 self-tapping sheet metal screws (not included), screw in through the dimple on both sides.

The Flex-A-Spout extends from 25" to 55". If 55" is not long enough, simply cut the ends off a second Flex-A-Spout and snap them together.